To installation see operating instructions of your respective LAUDA Thermostat.

Socket 71S (till now)		**Socket 74S (from 2007 on)**
Pin 1 Output 1 Pin 2 Output 2 Pin 3 0V reference potential Pin 4 Input 1 ***Pin 5 0V reference potential*** Pin 6 Input 2		Pin 1 Output 1 Pin 2 Output 2 Pin 3 0V reference potential Pin 4 Input 1 ***Pin 5 +24 V (max. 0,1 A)*** Pin 6 Input 2
		Modification of pin assignment from contact 5.
		

YAAE0021 / 12/06
Valid from series: LRZ 912 PIN 5: +24Volt

LAUDA DR. R. WOBSER GMBH & CO. KG
P.O. Box 1251
97912 Lauda-Königshofen
Germany
Telephone: +49 (0)9343/ 503-0
Fax: +49 (0)9343/ 503-222
E-Mail info@lauda.de
Internet http://www.lauda.de